



Tempasure

Quality Assurance for Low Temperature Sensitive Products

Descending Temperature points

Instructions for Use

Allow sensor to stabilize at product temperature

Pull safety tab to activate sensor

Remove release liner and attach with self-adhesive backing

A clear window indicates that the unit has not been exposed to critical low temperature

Indicator window shows red when exposed to a low temperature that is at or below its rating